

The Nest Healesville Accommodation – What happens if I run out of hot water?

The Nest hot water heats overnight to take advantage of the lower power rates.

If you run out of hot water you can manually make the system reheat by using the following method.

1. Locate the Electrical meter box at the front corner of the house, nearest to the driveway.
2. Find the smart meter inside.
3. Press and hold the second “Boost” button for about 5 seconds, whilst the boost countdown is shown.
4. The display should read:

BOOST 3

BOOST 2

BOOST 1

BOOST ON

The water heater will now reheat no matter what time of day it is. Reheating may take a few hours.



Hot Water Boost button

