


The Nest Healesville Accommodation – Dryer Instructions



1. Door
2. Filter
3. Start button for switching the machine on
4. Low heat drying button for careful drying at a reduced temperature
5. Selector for drying time
6. Setting marks
7. Programme display
8. Indicator lamp

NOTE: Please leave cupboard doors open when drying