


The Nest Healesville Accommodation – Dishwasher Instructions

- Pull door firmly by handle to open the dishwasher
- Make sure washing powder/pellet is in the door soap dispenser
- Make sure that the machine is on to use it – button (1)
- Select the washing program with the program button (5)
- Close the door to start (push door until it clicks closed)



Control Panel



- 1 ON/OFF Button: To turn ON/OFF the power supply.
- 2 Power Light : To come on when the ON/OFF Button is Pressed down.
- 3 Delayed Start Button: Press this button to set the delayed hours required prior to the wash program. You can delay the start of washing up to 24 hours. One press on this button delays the start of washing by one hour.
- 4 LED Display Panel: Delay timer and P1 to P7 will be displayed here. P1 to P7 corresponds to the seven programmes.
- 5 Program Button: Press the button to choose the desired program.
- 6 Half Load Wash button – press: To select the half load wash program. (It means that the lower spray arm does not run, so you should load the upper basket only).
- 7 Half Load Light : To come on when the half load program has been selected.
- 8 LED Display Panel: Program remaining time, delay time, running indicator, fault codes and etc.

Wash Cycle Table

Program	Cycle	Cycle Selection Information	Description of Cycle	Detergent pre/main	Rinse Aid
Intensive		For the heaviest soiled loads, such as pots, pans, casserole dishes and dishes that have been sitting with dried food on them for a while.	Pre-wash (45 °C) wash (50 °C/70 °C) Rinse Rinse (70 °C) Drying.	5/25 g	★
Heavy		For heavy soiled loads, such as pots, plates, glasses and lightly soiled pans.	Pre-wash Pre-program Wash (50 °C) Rinse Rinse (70 °C) Drying.	5/25 g	★
Normal	 (AS/NZS 2007.1)	For normal soiled loads, such as pots, plates, glasses and pans. standard daily cycle.	Pre-wash Pre-Wash Wash (50 °C) Rinse 60 °C Drying.	5/25 g	★
Rinse		For dishes that need to be rinsed and dried only.	Rinse Rinse (70 °C) Drying.		★
Glass		A shorter wash for lightly soiled loads that do not need drying.	Pre-wash Wash (40 °C) Rinse Rinse (60 °C) Drying.	15 g.	★
Rapid		For very lightly soiled loads, such as glasses, crystal and fine china.	Wash (40 °C) Rinse Rinse	15 g.	
Soak		Pre-wash of dishes, pots and pans while waiting for the load to be completed after the subsequent meal.	Rinse		